



Engine - Engine

Diagnosis and Testing

Special Tool(s)	
 E36420	Digital multimeter
 E36439	Generic scan tool



Symptom Chart

Symptom Chart

Symptom	Possible Sources	Action
DTC P1392 VVT solenoid A circuit low input	* Solenoid coil open circuit * Harness open circuit or blown fuse * Connector pins(s) bent, loose or corroded	* GO to Pinpoint Test A
DTC P1397 VVT solenoid B circuit low input	* Solenoid coil open circuit * Harness open circuit or blown fuse * Connector pins(s) bent, loose or corroded	* GO to Pinpoint Test A
DTC P1393 VVT solenoid A circuit high input	* Solenoid coil short circuit * Harness short circuit * Connector pins(s) bent, loose or corroded	* GO to Pinpoint Test B
DTC P1398 VVT solenoid B circuit high input	* Solenoid coil short circuit * Harness short circuit * Connector pins(s) bent, loose or corroded	* GO to Pinpoint Test B
DTC P1396 VVT solenoid B malfunction	* Oil pressure failure * VVT solenoid sticking * Connector pins(s) bent, loose or corroded * Crankshaft position sensor failure * ECM failure	* GO to Pinpoint Test C

Pinpoint test A: P1392 (P1397) VVT solenoid circuit low input

PINPOINT TEST A : P1392 (P1397) VVT SOLENOID CIRCUIT LOW INPUT	
• NOTE: References in brackets are for Bank B (2)	
TEST CONDITIONS	DETAILS/RESULTS/ACTIONS
A1: RETRIEVE DTCS	
• NOTE: Battery and or ECM disconnection prior to scanning will erase all data, ensure that the correct DTC is present.	



C1137.A1

E32153

1 Connect the scan tool

Have the DTC(s) and freeze frame data been recorded?

Yes

GO to **A2**

A2: CHECK FUSE / RELAY

1



E34925

1 Check that fuse F12 is good and that EMS control relay is energized

OK?


Yes

GO to **A3**

No

Rectify as required

A3: CHECK VVT COIL RESISTANCE



E32080




1 With VVT connector PI031 - A bank or (PI032 - B bank) disconnected, measure the resistance between the pins 1 and 2 at the VVT actuator

Is the resistance less than 5 OHM or greater than 20 OHM?

Yes
Renew the VVT solenoid and test the system for normal operation.

No
GO to **A4**

A4: CHECK HARNESS CONTINUITY



E32081

- 1 With EM015 and PI031 (PI032) disconnected, measure the resistance between EM015/009 (EM015/008) and PI031/001 (PI032/001)

Is the resistance < 0.5 OHM?


Yes

GO to **A5**

No

Inspect harness / connectors EM015, PI031 (PI032), PI001/016 (PI001/027) for corrosion, damage, bent or pushed back pins and repair as required. Test the system for normal operation.

A5: CHECK HARNESS (GROUND) CONTINUITY





E32082

	<p>1 With EM014 disconnected, measure the resistance between EM014/009 and ground EM016L</p> <p>Is the resistance < 0.5 OHM?</p> <p>Yes Reconnect EM014, EM015, PI031 or (PI032) GO to A6</p> <p>No Inspect harness / connector EM014, ground stud and splice EMS37 for corrosion, damage, bent or pushed back pins and repair as required. Test the system for normal operation.</p>
<p>A6: END</p>	<p>1 Perform appropriate service drive cycle and check for the presence of DTC.</p> <p>Has the fault code cleared?</p> <p>Yes STOP</p> <p>No Contact Jaguar Service</p>

Pinpoint test B: P1393 (P1398) VVT solenoid circuit high input

<p>PINPOINT TEST B : P1393 (P1398) VVT SOLENOID CIRCUIT HIGH INPUT</p>	
<p>• NOTE: References in brackets are for Bank B (2)</p>	
<p>TEST CONDITIONS</p>	<p>DETAILS/RESULTS/ACTIONS</p>
<p>B1: RETRIEVE DTCS</p>	<p>• NOTE: Battery and or ECM disconnection prior to scanning will erase all data, ensure that the correct DTC is present.</p>



C1137.A1

E32153



1 Connect the scan tool

Have the DTC(s) and freeze frame data been recorded?


Yes

GO to **B2**

B2: CHECK VVT COIL CONTINUITY



3



E32083

1 With VVT connector PI031 - A bank or (PI032 - B bank) disconnected, measure the resistance between the pins 1 and 2 at the VVT actuator

Is the resistance >20 OHM?


Yes

Renew the VVT solenoid and test the system for normal operation.

No

GO to **B3**


B3: CHECK SHORT TO B+



E32085

- 1** Remove fuse F12
 - 2** With EM015, EM014, PI031 or (PI032) disconnected, measure the voltage between EM015/009 (EM015/008) and EM014/009
- 0 V?
Yes
 Reconnect EM015 and EM014 and replace fuse F12
 GO to **B4**
- No**
 Inspect EM015, PI031 or (PI032) for bent / pushed back pins or locate and repair the harness / connector PI001/016 or (PI001/027) Test the system for normal operation.

B4: CHECK B+ AT VVT SOLENOID



E32084

1 Measure the voltage between PI031/002 (PI032/002) and ground EM016L

B+ ?


Yes

GO to **B5**

No

Inspect EM020/010, PI001, PI031 (PI032) for bent / pushed back pins or locate and repair harness / splice PIS06.

B5: CHECK HARNESS SHORT TO GROUND



E2080

1 With EM015 and EM014 disconnected, measure the insulation resistance between EM015/009 (EM015/008) and ground EM014/009

Is the resistance > 10 MOHM?


Yes

Do not reconnect
GO to **B6**

No

Inspect EM015, and EM014 for corrosion, bent / pushed back pins or locate and repair the harness / connector. Test the system for normal operation.

B6: CHECK HARNESS SHORT CORE TO CORE



E32086

1 With EM015, EM014 PI031 and PI032 disconnected, measure the insulation resistance between EM015/009 and EM015/008

Is the resistance > 10 MOHM?

Yes

Reconnect all connectors
GO to **B7**

No

Inspect EM015 and PI031 (PI032) for corrosion, bent / pushed back pins or locate and repair the harness / connector PI001/016 (PI001/027). Test the system for normal operation.

B7: END

1 Perform appropriate service drive cycle and check for the presence of DTC

Has the fault code cleared?

Yes




STOP

No

Contact Jaguar Service

Pinpoint test C: P1396 VVT solenoid malfunction

PINPOINT TEST C : P1396 VVT SOLENOID MALFUNCTION	
TEST CONDITIONS	DETAILS/RESULTS/ACTIONS
C1: RETRIEVE DTCS	
• NOTE: Battery and or ECM disconnection prior to scanning will erase all data, ensure that the correct DTC is present.	



C1137.A1

E32153



1 Connect the scan tool

Have the DTC(s) and freeze frame data been recorded?

Yes

GO to **C2**

C2: CHECK VVT COIL CONTINUITY



E32087

1 With VVT connector PI032 disconnected, measure the resistance between the pins 1 and 2 at the VVT actuator

Is the resistance >20 OHM?


Yes

Renew the VVT solenoid and test the system for normal operation.

No

GO to **C3**

C3: CHECK SHORT TO B+



E32088

1 Remove fuse F12

2 With EM015, EM014, PI031 and PI032 disconnected, measure the voltage between EM015/008 and EM014/009

0 V?


Yes

Reconnect EM015 and EM014 and replace fuse F12
GO to **C4**

No

Inspect EM015, PI001 or PI032 for bent / pushed back pins or locate and repair the harness / connector. Test the system for normal operation.

C4: CHECK B+ AT VVT SOLENOID



E32089

1 Measure the voltage between PI032/002 and ground EM016L

B+ ?


Yes

GO to C5

No

Inspect EM020/010 PI031 (PI032) for bent / pushed back pins or locate and repair harness / splice PIS06. Check fuse F12 is good and EMS control RELAY 1 energized. Test the system for normal operation.

C5: CHECK HARNESS SHORT TO GROUND



E32090

1 With EM015 and EM014 disconnected, measure the insulation resistance between EM015/008 and ground EM014/009

Is the resistance > 10 MOHM?

Yes

Do not reconnect
GO to **C6**

No


Inspect EM015, and EM014 for corrosion, bent / pushed back pins or locate and repair the harness / connector. Test the system for normal operation.

C6: CHECK HARNESS SHORT CORE TO CORE


1



2



3



E32091

1 With EM015, EM014, PI031 and PI032 disconnected, measure the insulation resistance between EM015/009 and EM015/008

Is the resistance > 10 MOHM?



Yes

Reconnect all connectors
GO to **C7**



No

Inspect EM015, PI031 and PI032 for corrosion, bent / pushed back pins or locate and repair the harness / connector PI001/016 or PI001/027. Test the system for normal operation.

C7: CHECK HARNESS CONTINUITY



3



E32092

1 With EM015 and PI032 disconnected, measure the resistance between EM015/008 and PI032/001

Is the resistance < 0.5 OHM?


Yes

GO to **C8**

No

Inspect harness / connectors EM015, PI032 and PI001/027 for corrosion, damage, bent or pushed back pins and repair as required. Test the system for normal operation.

C8: CHECK HARNESS (GROUND) CONTINUITY



E32093

1 With EM014 disconnected, measure the resistance between EM014/009 and ground EM016L

Is the resistance < 0.5 OHM?

Yes

Reconnect EM014, EM015, PI031 or (PI032)
GO to **C10**

No

Inspect harness / connector EM014, ground stud and splice EMS037 for corrosion, damage, bent or pushed back pins and repair as required. Test the system for normal operation.

C9: CHECK MECHANICAL CONDITION

1 Remove the VVT(s) and ensure that there is no foreign matter blocking the oil passageway

OK?

Yes

GO to **C10**

No

Rectify as required

C10: END

1 Perform appropriate service drive cycle and check for the presence of DTC.

Has the fault code cleared?

Yes



STOP


No

Contact Jaguar Service

Engine - Valve Clearance Adjustment

General Procedures

Special Tool(s)	
 E36404	Tappet adjustment 303-540
 E36428	Air gun, fan nozzle 303-590



1. Open the engine compartment and fit paintwork protection sheets. Open to the service position.
2. Carefully remove both engine covers, taking care not to damage the plastic fixings or the rubber inserts.
3. Disconnect the battery ground cable.

- Remove the battery cover.

4. Remove the cam cover from the 'A' bank and the 'B' bank; including the purge valve, the on-plug ignition coils and the air intake tube / air flow meter / air cleaner cover assembly. Refer to Operations 12.29.43 and 12.29.44.
5. Check, and note the valve clearances, as described earlier in this section.
6. Use a rag to wipe up as much oil as possible from the tappet wells.
7. Valve adjustment involves considerable repetition. A SUMMARY OF THE PROCEDURE follows:

1. Fit the adjusting tool base plate to one cylinder head.
2. Rotate the crankshaft to position four valves ready for adjustment.
3. Use the attachment part of the special tool to adjust two valve clearances. Transfer the attachment and adjust the other two valve clearances.
4. Remove the attachment part from the adjusting tool base plate.