



V8 XJ Series/XK8

DATE 2/98

303-14

SERVICE

TECHNICAL BULLETIN

## Low Coolant Level – Warning Lamp Illuminated

MODEL  
1997 MY-ON XK8 Range  
1998 MY-ON V8 XJ Series  
VIN  
001001-ON  
812256-ON

### Issue:

When a new vehicle is factory-filled with antifreeze solution, small pockets of air may remain trapped in the cooling system. On a new vehicle, these pockets of air may take some considerable time to be purged, resulting in a gradual drop in the coolant level. This process may eventually lead to illumination of the coolant warning lamp by the low level sensor located in the coolant reservoir.

Once the coolant level has dropped, it is also possible that the captive float which actuates the low level sensor may stick in the down position, leaving a warning on even after the cooling system has been refilled.

### Action:

When investigating a customer complaint of low coolant level warning light remaining on proceed as follows:

#### A. TOPPING-UP THE COOLING SYSTEM.

The following procedure assumes that only a minor top-up of the coolant is required - a maximum of 1 quart of coolant. Any causes of major leakage must be repaired before continuing.

1. With the engine **cold**, remove the pressure cap from the coolant reservoir. Check the pressure cap seal - replace if necessary. Visually check the coolant level. If low, continue with the procedure below.
2. If the coolant level is below the bottom of the filler neck, top up with Jaguar Antifreeze D542 (diluted 50:50 with clean water) until the coolant rises to the bottom of the filler neck.
3. Start the engine and allow it to run at idling speed. The coolant level may fall in the coolant reservoir. With the engine still running, immediately top up the coolant to the bottom of the filler neck.
4. Before the coolant temperature has a chance to increase, fully tighten the pressure cap on the coolant reservoir.
5. Before stopping the engine, check that the coolant warning lamp is off.



V8 XJ Series/XK8

DATE 2/98

303-14

SERVICE

## TECHNICAL BULLETIN

Low Coolant Level –  
Warning Lamp Illuminated

## MODEL

1997 MY-ON XK8 Range  
1998 MY-ON V8 XJ Series

## VIN

001001-ON  
812256-ON**Issue:**

When a new vehicle is factory-filled with antifreeze solution, small pockets of air may remain trapped in the cooling system. On a new vehicle, these pockets of air may take some considerable time to be purged, resulting in a gradual drop in the coolant level. This process may eventually lead to illumination of the coolant warning lamp by the low level sensor located in the coolant reservoir.

Once the coolant level has dropped, it is also possible that the captive float which actuates the low level sensor may stick in the down position, leaving a warning on even after the cooling system has been refilled.

**Action:**

When investigating a customer complaint of low coolant level warning light remaining on proceed as follows:

**A. TOPPING-UP THE COOLING SYSTEM.**

The following procedure assumes that only a minor top-up of the coolant is required - a maximum of 1 quart of coolant. Any causes of major leakage must be repaired before continuing.

1. With the engine **cold**, remove the pressure cap from the coolant reservoir. Check the pressure cap seal - replace if necessary. Visually check the coolant level. If low, continue with the procedure below.
2. If the coolant level is below the bottom of the filler neck, top up with Jaguar Antifreeze D542 (diluted 50:50 with clean water) until the coolant rises to the bottom of the filler neck.
3. Start the engine and allow it to run at idling speed. The coolant level may fall in the coolant reservoir. With the engine still running, immediately top up the coolant to the bottom of the filler neck.
4. Before the coolant temperature has a chance to increase, fully tighten the pressure cap on the coolant reservoir.
5. Before stopping the engine, check that the coolant warning lamp is off.

**Parts Information:**

<u>DESCRIPTION</u>	<u>PART NUMBER</u>	<u>QTY</u>
Jaguar Antifreeze D 542	JLM 20404/3	a/r

**Warranty Information:**

<u>FAULT</u>	<u>R.O.</u>	<u>DESCRIPTION</u>	<u>TIME</u>
<u>CODE</u>	<u>NUMBER</u>		<u>ALLOWANCE</u>
DB ** **	26.91.06	Check level sensor float and top off cooling system	0.15 hrs.
	10.10.10	Drive in/drive out	0.15 hrs.

\*\*\* BB ZZ = Coolant level - incomplete factory fill  
BD NS = Coolant level sensor float sticking

\* This Warranty Fault Code and SRO are no longer valid after the vehicle has received its First Routine Service at nominal 10,000 miles (16,000 km).