

ELECTRICAL

CONSTANT ENERGY IGNITION

OPERATION

86.35.00

A voltage signal generated by the reductor and pick up assembly is interpreted by the amplifier which switches on and off the current flowing in the primary winding of the HT coils. When a reductor tooth passes across the pick up limb, the magnetic field strength around the pick up winding is intensified creating a voltage in the winding. The rise and fall of this voltage is sensed by the amplifier and is used to trigger the output of the transistorised amplifier.

Two HT coils are incorporated on the V12 HE engines. The main coil primary winding is connected in parallel with the primary winding of the auxiliary coil. The HT section of the auxiliary coil is not used and the HT outlet is sealed.

The auxiliary coil enables the ignition system to achieve the required performance at high engine speeds under load.

There is no separate ballast resistor in the circuit. The amplifier controls the maximum current flowing in the primary circuit.

The fuel injection lead to the ECU and the lead to the tachometer are taken from the amplifier. The distributor incorporates the standard automatic advance system. The traditional cam and contact breaker are replaced by an antflash shield, reductor, and pick up assembly. The reductor is a gear like component with as many teeth as there are cylinders to the engine and is mounted on the distributor shaft in place of the cam. The pick up consists of a winding around a pole piece attached to a permanent magnet, and is prewired with two leads terminating in a moulded two pin inhibited connector. During normal service the air gap between the reductor and the pick-up does not alter and will only require re-setting if it has been tempered with. The normal setting is 0.20 to 0.35 mm (0.008 to .014 in).

The pick-up resistance should be 2 to 5 K ohms.

The amplifier assembly consists of a solid state electronic amplifier module, a zenor diode to protect the amplifier in the event of a current surge, a suppression capacitor and a moulding containing two resistors.

The amplifier is a sealed unit containing 'BERYLIA'.

WARNING: THIS SUBSTANCE IS EXTREMELY DANGEROUS IF HANDLED. DO NOT ATTEMPT TO OPEN THE AMPLIFIER MODULE.




Fig 1

- 1 Distributor
- 2 Amplifier
- 3 HT Coil
- 4 To ECU
- 5 To Tachometer
- 6 To Ignition Switch

ELECTRICAL

Ignition timing 5.3 Litre

P injection

A Emissions (USA) Pre 1983 25" – 27" BTDC.
A Emissions (USA) 1983 on 18" BTDC.
B Emissions (UK & Europe) Not HE 24" BTDC.
 Engine hot at 3000 rev/min
B Emissions (UK & Europe) HE 18" BTDC
 Vacuum pipe disconnected.

Initial setting to start the engine only

A Emissions 9° + or – 1° BTDC
B Emissions 4" + or – 1° BTDC

Ignition Timing 3.6 Litre

Federal 18" BTDC at 2000 rev/min with vacuum pipe disconnected engine hot
European 2 1° BTDC at 2000 rev/min with vacuum pipe disconnected engine hot

FAULT FINDING

Test 1

Check battery. A heavy discharge test applied to the battery terminals will determine whether the battery is capable of supplying the heavy currents required by the starter motor.

Check the specific gravity of the electrolyte in each cell. A variation of 0.040 in any cell means the battery is suspect.

Test 2

Check for HT spark. Remove the HT lead from the centre of the distributor cap and position the end of the lead approximately 6 mm (0.25 in) from a good earth on the engine.

Crank the engine and if a spark is obtained, check the HT leads, spark plugs, distributor cover, and the rotor.

Test 3

With the ignition switched on. The voltage at the positive terminal of the MAIN coil 'C' should be 12 volts. If the voltage is below 11 volts check the wiring to/from the ignition switch.

Test 4

Disconnect the leads from the negative terminal of the MAIN coil. With the ignition switched on a 12 volt reading should be obtained from the negative terminal. A zero reading would indicate a faulty MAIN coil. If a 12 volt reading is obtained, reconnect the disconnected leads to the main coil and repeat Test 3 and 4 at the AUXILIARY coil.

ELECTRICAL

Test 5

Disconnect the distributor pick-up leads from the amplifier. Measure the resistance of the distributor pick-up. It should be 2.2 to 4.8K ohms. An incorrect reading indicates a faulty pick-up coil.

Test 6

Connect a voltmeter between the positive terminal of the battery and the negative terminal of the main coil. Switch on the ignition and the voltmeter should indicate a zero reading. Crank the engine and the voltmeter reading should rise to between 2 and 3 volts. If the voltmeter remains at zero the amplifier is suspect.

FRONT AND REAR PARKING LAMPS

CIRCUIT DESCRIPTION

86.40.00

With the master light switch in the parking lamp on position current flows to the lamp via the switch contacts A and B, the bulb failure units and fuses. The current flowing through the bulb failure units will cause the bulb failure warning lamp to glow for 15 to 30 seconds. If the warning lamp fails to go out, then there is a bulb failure or a circuit fault in the front parking lamp, rear lamps, or number-plate lamps.

Fault Finding

Check the fuses and all connections, ensuring the earth connections are clean and tight.

With the master light switch in the parking lamp on position, battery voltage should be obtained at the B and the L terminals of the bulb failure unit.

If battery voltage is obtained at the B terminal but a zero reading at the L terminal replace the bulb failure unit.

HEAD AND FOG LAMPS

CIRCUIT DESCRIPTION

86.40.00

With the master light switch in the headlamp position the contacts are connected together in the main lighting switch to supply power to the headlamp relay. The headlamp flash switch activates the headlamp relay which in turn selects the main or dip headlamp filaments.

When the rear fog guard lamps are selected contacts are connected together to supply power to the rear fog guard lamps. The headlamp inhibit relay is also energised supplying current to the headlamp dip filaments only.


ELECTRICAL HARNESSES, COMPONENTS AND CIRCUITS

RH FORWARD HARNESS

Key to Diagram

- 1 Alternator
- 2 Load dump module
- 3 Earth point
- 4 Extra air valve relays
- 5 Air conditioning compressor relay
- 6 Stop lamp relay
- 7 Starter relay
- 8 To bulkhead harness
- 9 Battery feed post
- 10 Starter motor
- 11 Speed control actuator
- 12 Engine harness plug

RH FORWARD HARNESS




ELECTRICAL HARNESSES, COMPONENTS AND CIRCUITS

LH FORWARD HARNESS

Key to Diagram

- 1 RH side marker
- 2 Earth point
- 3 RH headlamp
- 4 RH side lamp
- 5 RH heated jets
- 6 Low level sensor
- 7 RH fog lamp
- 8 Ambient sensor
- 9 Horns
- 10 LH heated jet
- 11 Radiator fan terminal
- 12 To wash/wipe harness
- 13 LH headlamp
- 14 LH fog lamp
- 15 LH side lamp
- 16 Earth point
- 17 Low coolant probe
- 18 LH side marker
- 19 Ignition sense dim/dip relay
- 20 Side lamp sense dim/dip relay
- 21 Cooling fan diode pack
- 22 Horn relay
- 23 Cooling fan relay
- 24 Headlamp relay
- 25 Fuse boxes
- 26 To bulkhead harness

ENGINE HARNESS 5.3



ENGINE HARNESS 5.3

Key to Diagram

- 1 HT ignition coil
- 2 Speed control actuator
- 3 Injectors
- 4 Auxiliary coil
- 5 Throttle micro switches
- 6 Ballast resistor


ELECTRICAL HARNESSES, COMPONENTS AND CIRCUITS

FUEL INJECTION HARNESS 5.3

Key to Diagram

- 1 Ballast resistor
- 2 ECU
- 3 Micro switch
- 4 HT coil
- 5 Ignition amplifier
- 6 Air filter
- 7 Air temperature sensor
- 8 Coolant temperature sensor
- 9 Distributor

FUEL INJECTION HARNESS 5.3




ELECTRICAL HARNESSSES, COMPONENTS AND CIRCUITS

REAR HARNESS 5.3

Key to Diagram

- 1 LH rear fog lamp
- 2 Caravan socket
- 3 Rear lamp
- 4 Earth point
- 5 Tail lamp bulb failure sensor
- 6 Boot lamp
- 7 Speed interface unit
- 8 Boot lamp switch
- 9 Heated rear screen
- 10 Quarter light motor
- 11 Interior lamp
- 12 Heated rear screen disable switch
- 13 Speaker
- 14 Seat heater
- 15 Lumbar motor
- 16 Heated rear screen
- 17 Seat belts
- 18 Seat switch
- 19 Hoof lift switch
- 20 Earth point
- 21 Seat switch
- 22 Speakers
- 23 To bulkhead harness
- 24 Interior lamp
- 25 Quarter light motor
- 26 To hood lift harness
- 27 Handbrake switch
- 28 To boot lid harness
- 29 Fuel gauge transmitter
- 30 Fuel pump relay
- 31 Fuel injection main relay
- 32 Fuel interface module
- 33 Fuel injection ECU
- 34 Earth point
- 35 Battery leads
- 36 Fuel pump
- 37 To rear axle speed sensor
- 38 Boot lamp
- 39 Aerial delay unit
- 40 Rear lamp
- 41 RH rear fog lamp

REAR HARNESS 5.3



J86-726


ELECTRICAL HARNESSSES, COMPONENTS AND CIRCUITS

COMPONENT LOCATION 5.3 LHD

Key to Diagram

- 1 Headlamp relay
- 2 Coolingfan relay
- 3 Horn relay
- 4 Cooling fan diode pack
- 5 Anti stall relay
- 6 Anti stall relay
- 7 Ballast resistor
- 8 Load dump module
- 9 Air conditioning compressor relay
- 10 Feedback inhibit relay
- 11 Stop light relay
- 12 Starter relay
- 13 Door lock control unit (Kiekert)
- 14 Vacuum delay unit
- 15 Windscreen wiper delay unit
- 16 ABS pump relay
- 17 Interior light delay unit
- 18 Seat heater delay unit
- 19 Window lift relay
- 20 Seat belt logic unit
- 21 Bulb failure unit
- 22 Low coolant warning control unit
- 23 Window lift thermal circuit breaker
- 24 Bulb failure unit
- 25 Auxiliary fuse box
- 26 Fuel injection electronic control unit
- 27 Fuel pump relay
- 28 Fuel injection main relay
- 29 Fuel interface unit
- 30 Rear lamp bulb failure unit
- 31 Aerial delay unit
- 32 Feedback monitor sockets
- 33 Rear lamp bulb failure module
- 34 Speed control interface module
- 35 ABS control unit
- 36 ABS main relay
- 37 Inertia switch
- 38 Heated seat relay
- 39 Heated rear window delay unit
- 40 Lumbar support relay
- 41 Fog light relay
- 42 Flasher unit
- 43 Warning light check unit
- 44 ABS pump relay
- 45 Main fuse box
- 46 Stoplight bulb failure module
- 47 Quarter light down relay
- 48 Quarter light up relay
- 49 Hood down relay
- 50 Hood up relay
- 51 Quarter light down relay
- 52 Quarter light up relay
- 53 Hood electronic control unit
- 54 Headlamp fuse box B
- 55 Headlamp fuse box A

COMPONENT LOCATION 5.3 LHD



J86-659


ELECTRICAL HARNESSSES, COMPONENTS AND CIRCUITS

IGNITION, ALTERNATOR AND STARTER SYSTEMS 5.3

Key to Diagram

- 1 Battery
- 2 Alternator
- 3 Warning light
- 4 Ignition switch
- 5 To fuse No 12
- 6 Automatic gearbox safety switch
- 7 Ignition protection relay
- 8** To tachometer
- 9 Main HT coil
- 10 Auxiliary coil
- 11 Starter relay
- 12 Amplifier
- 13 Distributor
- 14 To ECU
- 15 Starter motor
- 16 To ECU

IGNITION, ALTERNATOR AND STARTER SYSTEMS 5.3



ELECTRICAL HARNESSES, COMPONENTS AND CIRCUITS

IGNITION SYSTEM 5.3

Key to Diagram

- A Distributor
- B Amplifier
- C HT coil
- D Auxiliary coil
- G Ignition switch
- E To ECU
- F To tachometer

IGNITION SYSTEM 5.3

