

Jaguar F-Type V6/V6S

Gear Shift Removal

1. Lift up shift boot bezel from rear
2. Pull down on collar under shift knob (in photo, finger points to collar)
3. Lift up on shift knob with force. Shift knob and boot come off as unit.
4. Remove sound padding.
5. Remove metal counterweight. Lift straight up.
6. Turn white plastic collar clockwise ¼ turn.
7. Remove black plastic shift lever by twisting and pulling in an upward direction. Takes substantial force.
8. Remove both black rubber sleeves by pulling up.
9. Remove white plastic cover and lower rubber shifter dust boot.
10. Use snap-ring pliers and turn large white plastic collar clockwise 1.4 turn.
11. Remove exhaust system.
12. Remove heat shields.
13. Remove 13mm bolt from shifter (on shifter rail behind transmission).
14. From inside car, pull out OEM shifter.

Installation

Reverse above process.