



Recommended Specs
 by Jaguar technician
 Please check toe deflection
 after setting toe and before
 finalizing everything and
 tightening everything up. (aka
 "Mercedes alignment with pressure
 bar"). Try to get total
 toe of 0.26. Thanks!

"Exhibit A"
 - alignment specs