



1995 VDP

Wiring Pass-Thru
Rear Shelf to Boot

Rear Seat Removal- Cushion

Remove LHS and RHS kick panels
Remove Cushion-fixing bolt adjacent
to kick-panel fixings

Stuff the seat belt buckles down in the
holes in order to free the cushion a bit



Kick-Panel Fixing

Seat Fixing



Before

After

Rear Seat Removal - Squab

Four fixings on this one

2 Outboard

2 Inboard, near the tunnel, not immediately visible



Squab Removal Cont'

Once fixings are removed, you need to lift the seatback to disengage it from these clips

The considerable padding/sound insulation may be peculiar to the VDP. I recall someone else has posted a pic of the rear wall and steel was visible with a few foam pads here and there.



Parcel Shelf Left Side

Use a trim tool to prise the christmas-tree fastener up near the left D-pillar and find a grommet with a wiring loom.

I only needd to route a small duplex wire from the solar charger through, so elected to go between the grommet and shelf, rather than try to thread it through the grommet with the other wires. I added a small bit of adhesive-backed anti-chafe film that I had on-hand to the edge of the hole.



Final Destination

