

VAC HOSE TO SPIGOT
ON REAR OF "A"
INLET MANIFOLD

DUMP VALVE

TO FUEL LOAD SWITCH
AKA - BLUE/WHITE VALVE

TO VAC ADVANCE UNIT

THROTTLE
BODY
"A" BANK

UNDERSIDE
VAC SPIGOT

DOUBLE "T" ~~PIECE~~ JOINER
OR USE 2 X SINGLE "T" JOINERS

