

2015.0 F-TYPE (X152), 501-05

INTERIOR TRIM AND ORNAMENTATION

SCUFF PLATE TRIM PANEL (G1584223)


REMOVAL AND INSTALLATION

REMOVAL

NOTES:

- Removal steps in this procedure may contain installation details.
- Some components shown removed for clarity.

1.



INSTALLATION

1. To install, reverse the removal procedure.