## **Powertrain**

## Coolant Flow (V8 SC)

The diagram below shows the coolant flow at normal running temperature (thermostat open).




Fig. 40 Coolant-flow diagram (V8 SC)

- 1. Dual coolant-flow valve
- 2. EGR valve
- 3. Heater core
- 4. Throttle body
- 5. Charge air cooler (bank 1)
- 6. Coolant pump
- 7. Charge air cooler (bank 2)
- 8. V8 SC engine

- 9. Thermostat
- 10. Auxiliary coolant flow pump
- 11. Coolant expansion tank
- 12. Bottom hose
- 13. Radiator
- 14. SC Radiator
- 15. SC coolant pump
- 16. Top hose