

Automatic Transmission/Transaxle - Vehicles With: 5-Speed Automatic Transaxle - JATCO -

Lubricant, Sealers and Solvents

Description	Specification
High-temperature grease	ESD-M1C220-A
Metal surface cleaner	WSW-M5B392-A
Sealant	WSS-M4G323-A6

Fluid Maintenance



CAUTION: Use only WSS-M2C922-A1 automatic transmission fluid. Use of any other fluids may result in a transmission malfunction or failure.

Intervals	
Normal Maintenance	Not necessary. Filled for life.
Severe Duty Maintenance	Change the fluid at 48,000 km (30,000 miles) intervals.

General Specifications

Engine	Approximate Liters	Refill Capacity ¹ U.S. Quarts	Fluid Type
2.0l, 2.5L and 3.0L	8.8	8.32	WSS-M2C9 22-A1

¹ Approximate dry capacity, includes cooler and tubes. Check the level at normal operating temperature. DO NOT OVERFILL. If it is necessary to add or change fluid, use only fluid which has been certified by the supplier as meeting the Jaguar Cars Ltd specification shown.

Description	Nm	lb-ft	lb-in
Main control valve body screws	8	-	71
Torque converter access cover retaining bolts	10	-	89
Torque converter retaining bolts	55	41	-
Transaxle retaining bolts	48	35	-
Transaxle dust cover retaining bolt	10	-	89
Solenoid retaining bolt	8	-	71
Transaxle support insulator retaining nut	133	98	-
Transaxle mount bracket retaining bolts	80	59	-
Transmission control module retaining nuts	10	-	89
Transmission fluid drain plug	45	33	-
Transmission fluid level plug	15	11	-
Transmission mount to body retaining bolts	80	59	-
Transmission range sensor retaining bolts	10	-	89
Valve body cover retaining bolts	8	-	71
Starter motor retaining bolts	35	26	-
Starter motor solenoid electrical connector retaining nut	6	-	53
Starter motor electrical connector retaining nut	12	9	-
Wiring harness to camshaft cover retaining stud, retaining nut	6	-	53
Intake manifold support bracket retaining bolts	10	-	89
Air cleaner mount bracket retaining nuts and bolt	6	-	53
Left-hand driveshaft retaining nuts - vehicles with 2.0L and 2.0L diesel engine	25	18	-
Shock absorber and spring assembly securing nuts	25	18	-
Transaxle ground lead	25	18	-
Support bar retaining bolts	25	18	-