

Disabling Seatbelt Minder Function [Beltminder]

Although not advisable, it is possible to disable the seat belt minder function, as follows:

Note: This complete procedure must be completed within 60 seconds of the ignition being switched on.

1. With the front passenger seat unoccupied, turn on the ignition but do not start the engine.
2. Buckle the driver's seat belt and ensure that the warning light is extinguished.
3. Now unbuckle the driver's seat belt and wait until the warning light comes on.
4. Repeat steps 2. and 3. eight more times.
5. As the seat belt is unbuckled for the ninth time, a single chime will sound acknowledging that the seat belt minder has been disabled.

If the steps above are repeated, the seat belt minder function will be reinstated. If a heavy object is placed on the front passenger seat it may activate the Beltminder feature. It is recommended that the object be placed in the luggage compartment.

Notes: > No acknowledgement chime received on 2009 XF
> Applies to 2011 Range Rover, no acknowledgement and required key cycle.