

Published: 22-Jan-2015

## Glass, Frames and Mechanisms - Front Door Window Glass Removal and Installation


## Removal



1. *Torque:* <u>1.1 Nm</u>



2.




3.



## Installation

1. To install, reverse the removal procedure.



2.