

7/25/2016

JTB00415NAS4 - Loss Of Drive Or Flashing Gear Selector LED Indicator And / Or Related Intelligent Stop/Start Issues | TOPIX

9. Select **Run** to perform the **Configure existing module - Powertrain control module** option.
10. Follow all on-screen instructions to complete this task.
11. Select the **Selected Symptoms** tab and then select:
 - **Powertrain > Automatic transmission and transaxle > Automatic transmission and transaxle symptoms**
12. Select **Continue**.
13. Select the **Recommendations** tab.
14. Select **Run** to perform the **Configure existing module - Transmission control module** option.
15. Follow all on-screen instructions to complete this task, ensuring all Diagnostic Trouble Codes (DTC) are cleared.
16. When all tasks are complete, select the **Session** tab and then select the **Close Session** option.
17. Disconnect the diagnostic tool and battery power supply from the vehicle.