



E142724

With the hood open and the engine cover removed (see **190, FUSE BOX LOCATIONS**), connect jump leads to a suitable 12v supply. Then proceed as follows:

1. Remove the cover from the positive terminal.
2. Attach the positive jump lead clamp to the positive terminal.
3. Attach the negative jump lead clamp to the earthing post.

**Note:** The alarm may sound when the power is supplied.

4. Press the luggage compartment release button on the remote control.

**NOTICE**

Do not attempt to start the vehicle with power supplied in this way.