



XJ

QUICK START GUIDE

Rear seat entertainment

JAGUAR

## Basic controls




Location



Dock or undock

**Operating note.** The touch screen remote control can operate while docked or undocked.

If the control is undocked, ensure it is pointed towards the RSE screen in use.



1. Main power
2. Change audio channel
3. Headphone volume

## Watch a DVD - example uses the right screen



Load DVD into front head unit.  
Select the right screen.



DVD menu soft keys



**Operating note.** Navigate and select with menu soft keys. There may be a delay while the DVD responds.

## Listen to an iPod track - example uses the left screen



**Operating note.** Insert iPod into rear USB socket for audio playback.  
Use AV sockets for audio with video.



**Operating note.** Older iPod devices may not be compatible. Consult your Jaguar Dealer for details.

## Limousine mode – RSE control of infotainment system



Front Supervisor touch screen.  
Touch 1 then 2.



**Note.** Parental control is not applicable to North America.

## RSE control of cabin audio



**Operating note.** There may be a delay while the system responds. While Cabin Audio is ON, other audio sources can be played through the vehicle speakers.

## Front touch screen control of the RSE



Front Supervisor touch screen.  
Select a source from the Rear Media menu, e.g., Radio.



**Operating note.** While the Rear Media screen is displayed, the RSE remote control is disabled. The remote control can also be disabled via the Lock soft key.