

Fuel Filter

The fuel filter is of a conventional construction being that of a paper element sealed within a steel canister. The fuel filter is located on the left-hand front longitudinal member, under the left-hand splash shield.