

**COMPONENTS****Component**

CENTER CONSOLE SWITCH PACK  
 DOOR KEY BARREL SWITCH - DRIVER  
 DOOR LOCK ACTUATOR - DRIVER  
 DOOR LOCK ACTUATOR - LH REAR  
 DOOR LOCK ACTUATOR - PASSENGER  
 DOOR LOCK ACTUATOR - RH REAR  
 FASCIA TRUNK RELEASE SWITCH  
 FUEL FILLER FLAP ACTUATOR  
 IGNITION SWITCH  
 NOT IN-PARK MICROSWITCH  
 SECURITY AND LOCKING CONTROL MODULE

SHORTING LINK  
 TRUNK RELEASE ACTUATOR  
 TRUNK RELEASE SWITCH  
 VALET SWITCH

**Connector / Type / Color**

CC1 / 16-WAY MULTILOCK 040 / BLACK  
 DD3 / 13-WAY ECONOSEAL III LC / BLACK  
 DD3 / 13-WAY ECONOSEAL III LC / BLACK  
 RD3-L / 6-WAY ECONOSEAL III LC / BLACK  
 PD3 / 13-WAY ECONOSEAL III LC / BLACK  
 RD3-R / 6-WAY ECONOSEAL III LC / BLACK  
 FC12 / 16-WAY MULTILOCK 040 / BLUE  
 CABB / 2-WAY LABINAL / NATURAL  
 FC54 (FLY LEAD) / 8-WAY MULTILOCK 070 / WHITE  
 CC42 (FLY LEAD) / 2-WAY MULTILOCK 040 / BLACK  
 CA18 / 12-WAY MULTILOCK 47 / SLATE  
 CA19 / 22-WAY MULTILOCK 47 / SLATE  
 CA20 / 16-WAY MULTILOCK 47 / SLATE  
 CA21 / 26-WAY MULTILOCK 47 / SLATE  
 CA43 / 6-WAY MULTILOCK 070 / YELLOW  
 BT8 / 2-WAY LABINAL / BROWN  
 BT10 / 2-WAY MULTILOCK 040 / GREEN  
 CC47 / 2-WAY MULTILOCK 040 / BLACK

**Location / Access**

CENTER CONSOLE  
 DOOR CASING  
 DOOR CASING  
 DOOR CASING  
 DOOR CASING  
 DOOR CASING  
 DOOR CASING  
 STEERING COLUMN / DRIVER'S UNDERSCUTTLE  
 TRUNK, LF FRONT / TRUNK TRIM  
 STEERING COLUMN / COVER  
 'J' GATE / CENTER CONSOLE  
 TRUNK, LH FRONT / TRUNK TRIM  
 REAR SEAT, LH SIDE / UNDER  
 TRUNK LID / TRUNK LID TRIM  
 TRUNK LID / TRUNK LID TRIM  
 CENTER CONSOLE GLOVE BOX

**RELAYS****Relay**

DEADLOCK RELAY - DRIVER, LH REAR  
 DEADLOCK RELAY - PASSENGER, RH REAR  
 DOOR LOCK RELAY  
 DOOR UNLOCK RELAY  
 FUEL FILLER FLAP RELAY  
 TRUNK RELEASE RELAY

**Color / Stripe**

VIOLET  
 VIOLET  
 VIOLET  
 VIOLET  
 VIOLET  
 BLACK / VIOLET

**Connector / Color**

CA55 / VIOLET  
 CA55 / VIOLET  
 CA50 / VIOLET  
 CA50 / VIOLET  
 CA50 / VIOLET  
 CA97 / VIOLET  
 BT43 / VIOLET

**Location / Access**

LH HEELBOARD  
 LH HEELBOARD  
 LH HEELBOARD  
 LH HEELBOARD  
 LH HEELBOARD  
 LH HEELBOARD  
 TRUNK ELECTRICAL CARRIER

**HARNESS-TO-HARNESS CONNECTORS****Connector**

BT4  
 CA8  
 CA9  
 CA11  
 CA12  
 CA13  
 CA15  
 CC18  
 CC3  
 CC5  
 FC5  
 FC7

**Type / Color**

THROUGH-PANEL (48 MICRO / 6) / BLACK  
 20-WAY MULTILOCK 040 / GREEN  
 20-WAY MULTILOCK 040 / BLACK  
 20-WAY MULTILOCK 040 / BLACK  
 15-WAY MULTILOCK 070 / WHITE  
 12-WAY MULTILOCK 040 / BLACK  
 12-WAY MULTILOCK 040 / BLACK  
 20-WAY MULTILOCK 040 / BLUE  
 20-WAY MULTILOCK 040 / BLACK  
 20-WAY MULTILOCK 040 / GREEN  
 THROUGH-PANEL (48 MICRO / 6) / BLACK  
 THROUGH-PANEL (48 MICRO / 6) / BLACK

**Location / Access**

ABOVE FUEL TANK / FUEL TANK TRIM  
 DRIVER'S 'A' POST / 'A' POST TRIM  
 DRIVER'S 'A' POST / 'A' POST TRIM  
 PASSENGER'S UNDERSCUTTLE / ECM  
 PASSENGER'S UNDERSCUTTLE / ECM  
 LH 'BC' POST / 'BC' POST PANEL  
 RH 'BC' POST / 'BC' POST PANEL  
 CENTER CONSOLE / CENTER CONSOLE GLOVE BOX  
 CENTER CONSOLE / CENTER CONSOLE GLOVE BOX  
 CENTER CONSOLE / CENTER CONSOLE GLOVE BOX  
 LH FASCIA END PANEL / OUTER AIR VENT  
 PASSENGER'S UNDERSCUTTLE

**GROUNDS****Ground**

BTG49L  
 CAG91  
 CAG92R  
 CAG93L  
 CCG51L  
 FCG15L  
 FCG26R

**Location / Type**

REAR TRUNK GROUND STUD  
 PARCEL SHELF GROUND SCREW  
 RH HEELBOARD GROUND SCREW  
 LH HEELBOARD GROUND SCREW  
 CENTER CONSOLE GROUND STUD  
 LH CONSOLE GROUND STUD  
 LH CONSOLE GROUND STUD

**CONTROL MODULE PIN OUT INFORMATION (FOLD OUT PAGE)**

REFER TO THE FRONT OF THE BOOK FOR ILLUSTRATIONS DETAILING THE LOCATION AND IDENTIFICATION OF COMPONENTS, RELAYS, CONNECTORS, HARNESSSES, GROUNDS, VEHICLE CONTROL MODULES AND CONTROL MODULE PINS.