

8.2.28 SELECTOR CABLE ASSEMBLY – ADJUST

SRO 44.15.10.

- Remove the centre console veneer finisher panel.
- Remove the linear switch from the mounting bracket for access.
- Slacken both the front and rear adjusting / locknuts, and position them to the end of their threads.
- At the transmission unit, remove the selector cable from the transmission gear selector lever, and align the lever to the 'N' – neutral position.
- Reconnect the selector cable and secure with the nut (1 Fig. 1).
- At the centre console, adjust the cable adjusting / locknuts until the selector lever positively engages the 'N' position notch, then tighten the rear adjusting / locknut – ensure the tabwasher engages with the bracket slots.
- Refit the linear switch into position, and ensure that the peg engages with the selector sliding block, do not fully tighten the bolts. Adjust the linear switch see Sub Section 18.1.17.
- Refit the centre console veneer finisher panel, and the gear selector surround.
- Refit the performance mode switch and the ashtray.

