

EGR System

The EGR system is controlled by the ECM and consists of an EGR valve and a transfer pipe.

The EGR valve is a 4 pole stepper motor installed on the rear of the induction elbow. The valve is cooled by the coolant return from the electronic throttle.

The transfer pipe connects the right exhaust manifold to the EGR valve.

EGR VALVE AND TRANSFER PIPE

