



## Rear Seat Track

### Removal

1. Remove battery cover and disconnect ground cable from battery terminal. Refer to <<86.15.19>>.



2. Slacken and remove the two seat cushion front securing bolts and nuts.



3. Move the seat cushion forward to release it from the two frame rear tangs.



4. Disconnect the cushion heater harness multiplug and remove cushion from seat frame.



5. Remove and discard plastic scrivet securing lower end of side trim to inner wheelarch stud and withdraw trim from stud.



6. Push trim upwards to release keyhole aperture from squab fixing and partially withdraw trim for access.

