

P1384	VT solenoid malfunction – A bank	Drive vehicle; accelerate rapidly to cruise, decelerate to stop, repeat several times	Y	2	N	When CK ENG MIL is activated (DTC flagged; second trip). ECM: Sets VT drive PWM duty cycle to 0 (intake camshaft fully retarded)	VT solenoid valve to ECM PWM drive circuit fault VT solenoid valve to ECM ground circuit fault VT solenoid failure VT oil flow fault VT / camshaft mechanical failure
-------	-------------------------------------	---	---	---	---	---	---