

## COMPONENTS

### DESCRIPTION

CENTER CONSOLE  
CENTRAL MICROPROCESSOR  
CIGAR LIGHTER—FRONT  
CIGAR LIGHTER—REAR  
CLIMATE CONTROL PANEL  
COLUMN SWITCHES  
DIODE—LBD11  
FACIA SWITCH PACK  
GEAR POSITION INDICATOR MODULE  
INSTRUMENT PACK  
RADIO  
RELAY—AUXILIARY SIDE LIGHT (LB18)  
RELAY—RADIO LIGHTING (LB92)  
TRANSMISSION MODE SWITCH

### LOCATION

CENTER CONSOLE  
BEHIND GLOVE BOX  
CENTER CONSOLE ASHTRAY  
CENTER CONSOLE REAR PANEL  
CENTER CONSOLE  
STEERING COLUMN  
RIGHT LOWER 'A' POST, FORWARD  
ABOVE STEERING COLUMN  
'J' GATE  
DRIVER SIDE DASH  
CENTER CONSOLE  
COMPONENT PANEL  
PASSENGER FOOTWELL, 'A' POST  
'J' GATE

### ACCESS

CONSOLE SKI SLOPE PANEL  
UNDER DASH PANEL, RIGHT  
ASHTRAY  
CENTER GLOVE BOX  
CONSOLE SKI SLOPE PANEL  
STEERING COLUMN COVER  
PASSENGER FOOTWELL  
UNDER DASH PANEL, LEFT  
CONSOLE SKI SLOPE PANEL  
UNDER DASH PANEL, LEFT  
CONSOLE SKI SLOPE PANEL  
RIGHT DASH UNDER PANEL  
TRIM PANEL  
'J' GATE SURROUND

## CONNECTORS

CODE	DESCRIPTION	LOCATION / INTERFACE	CODE	DESCRIPTION	LOCATION / INTERFACE
AC1	24-WAY PMHD (YELLOW)	CENTER CONSOLE / AC CONTROL PANEL	LB43	4-WAY ECONOSEAL (WHITE)	CENTER CONSOLE / REAR CIGAR LIGHTER
GB2	15-WAY PMHD (BLACK)	CENTER CONS. SKI SLOPE PANEL / GB ILLUM. MODULE	LB49	24-WAY PMHD (GREEN)	LEFT DASH UNDER PANEL / FACIA SWITCH PACK
GB3	6-WAY AMP (WHITE)	CENTER CONS. SKI SLOPE PANEL / SPORT SWITCH	LB55	24-WAY PMHD (BLACK)	LEFT DASH UNDER PANEL / COLUMN SWITCHES
LB12	3-WAY PM4 (BLACK)	RIGHT DASH UNDER PANEL / CPU	LB66	15-WAY PMHD (BLACK)	CENTER CONSOLE, AC CONTROL PANEL / AC HARNESS
LB13	36-WAY PMHD (BLACK)	RIGHT DASH UNDER PANEL / CPU	LB92	RELAY BASE (YELLOW)	PASSENGER FOOTWELL, 'A' POST / RADIO LIGHT. RELAY
LB14	36-WAY PMHD (YELLOW)	RIGHT DASH UNDER PANEL / CPU	LB132	24-WAY PMHD (BROWN)	LEFT DASH UNDER PANEL / FACIA SWITCH PACK
LB18	RELAY BASE (GREEN)	RIGHT DASH UNDER PANEL / AUXILIARY SIDE LT. RELAY	LB134	24-WAY GROTE (BLACK)	BEHIND INSTRUMENT PACK / INSTRUMENT PACK
LB30	15-WAY PMHD (BLUE)	CENTER CONSOLE / CENTER CONSOLE SWITCH PANEL	LB135	48-WAY GROTE (BLACK)	BEHIND INSTRUMENT PACK / INSTRUMENT PACK
LB33	15-WAY PMHD (YELLOW)	CENTER CONSOLE / RADIO	LB157	4-WAY ECONOSEAL (WHITE)	CENTER CONS. SKI SLOPE PANEL / FRONT CIGAR LIGHTER
LB35	15-WAY PMHD (GREEN)	CENTER CONSOLE / GEAR POS. INDICATOR MODULE	LB158	4-WAY ECONOSEAL (WHITE)	CENTER CONS. SKI SLOPE PANEL / REAR CIGAR LIGHTER
LB38	4-WAY ECONOSEAL (WHITE)	CENTER CONSOLE / FRONT CIGAR LIGHTER	SCI	6-WAY PMHD (BLACK)	STEERING COLUMN COVER / DIMMER MODULE

## GROUNDINGS

CODE	DESCRIPTION	LOCATION / INTERFACE
LBG73	EYELET	CENTER CONSOLE ASHTRAY / POWER GROUND
LBG75	EYELET	BULKHEAD, BEHIND LEFT BLOWER AIR DUCT / POWER GROUND
LBG88	EYELET	RIGHT BULKHEAD, BEHIND DASH / POWER GROUND

## INPUTS / OUTPUTS

### CENTRAL MICROPROCESSOR

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
LB12-2	IN	BATTERY POWER	12V	12V
LB13-1	IN	IGNITION POWER	12V	0V
LB13-7	IN	INSTRUMENT LIGHTING	LIGHTS ON: GROUND	LIGHTS OFF: OPEN CIRCUIT
LB13-16	OUT	TIME CLOCK MEMORY	12V	0V
LB13-17	IN	KEY BOARD LIGHTING SWITCH	BUTTON IN: GROUND	BUTTON OUT: OPEN CIRCUIT
LB13-32	IN	CLOCK MOMENTARY LIGHTING	GROUND	OPEN CIRCUIT
LB13-36	IN	LOGIC GROUND	GROUND	GROUND
LB14-24	OUT	KEY BOARD LIGHTING	TIMED GROUND: 0V	DIMMER OUTPUT: 4.5-12V
LB14-29	OUT	INSTRUMENT LIGHTING	LIGHTS ON: GROUND	LIGHTS OFF: 12V
LB14-35	OUT	CLOCK DISPLAY W/ KEY ON	12V	0V
LB14-36	OUT	CENTER CONSOLE PANEL GROUND	GROUND: 0V	GROUND: 0V
LB90	IN	POWER GROUND		

### CLIMATE CONTROL PANEL

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
AC1-18	IN	LIGHTING GROUND	GROUND	GROUND
AC1-20	IN	LOCATE LIGHTING	DIMMER OUTPUT: 4.5-12V	0V
AC1-21	IN	AUXILIARY SIDE LIGHT RELAY	LIGHTS ON: GROUND	LIGHTS OFF: 12V

### CLOCK / CENTER CONSOLE

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
LB30-3	OUT	CLOCK MOMENTARY LIGHTING	MOMENTARY GROUND	OPENCIRCUIT
LB30-7	IN	DIMMER OVERRIDE	DIMMER ACTIVE: GROUND	DIMMER INACTIVE: 12V
LB30-11	IN	LOCATE LIGHTING	DIMMER OUTPUT: 4.5-12V	0V
LB30-13	IN	CLOCK DISPLAY POWER	12V	0V
LB30-14	IN	PERMANENT POWER	12V	12V
LB30-15	IN	POWER GROUND	GROUND	GROUND

### COLUMN SWITCHES

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
LB55-9	OUT	DIMMER OVERRIDE SWITCH	LIGHTS ON: GROUND	LIGHTS OFF: 12V
LB55-12	IN	BATTERY POWER	12V	12V
LB55-13	OUT	DIMMER CONTROL	4.5-12V	0V
LB55-16	IN	POWER GROUND		
LB55-20	OUT	DIMMER OVERRIDE SWITCH	DIMMER ACTIVE: GROUND	DIMMER INACTIVE: 12V
LB55-23	IN	DIMMER OVERRIDE SWITCH	LIGHTS ON: GROUND	LIGHTS OFF: APPROX .04V

### INSTRUMENT PACK

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
LB134-3	IN	LOGIC GROUND	GROUND	GROUND
LB134-4	IN	LOGIC GROUND	GROUND	GROUND
LB134-10	IN	GENERAL LIGHTING	12V	0V
LB135-38	IN	LCD MESSAGE DISPLAY LIGHTING	12V	0V

### FACIA SWITCH PACK

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
LB49-1	IN	FACIA LOCATE ILLUMINATION	DIMMER OUTPUT: 4.5-12V	0V
LB49-2	OUT	GEAR POSITION LIGHTING	KEY ON: 10V	KEY OFF: 0V
LB49-14	OUT	LIGHTS ON SIGNAL TO CPU	LIGHTS ON: GROUND	LIGHTS OFF: APPROX .07V
LB49-18	OUT	AUXILIARY SIDE LIGHT RELAY	GROUND	12V
LB49-20	IN	LOGIC GROUND	GROUND	GROUND
LB49-21	OUT	LIGHTS ON SIGNAL TO DIMMER CONTROL	LIGHTS ON: GROUND	LIGHTS OFF: APPROX .04V
LB49-22	IN	IGNITION POWER	12V	0V
LB49-24	IN	BATTERY POWER	12V	12V
LB132-3	IN	FACIA LOCATE ILLUMINATION	DIMMER OUTPUT: 4.5-12V	0V
LB132-16	IN	KEYBOARD ILLUMINATION	BUTTON IN: GROUND	0V
LB132-17	OUT	KEYBOARD ILLUMINATION	TIMED GROUND	12V



