



292 = EFI AMPLIFIER
 293 = ECU (IN BOOT)