

FIG 27 DATA

COMPONENTS

DESCRIPTION	LOCATION	ACCESS
CONVERTIBLE TOP ECU	LUGGAGE LOCKER	REMOVE COVER
CONVERTIBLE TOP FUSE	LUGGAGE LOCKER	REMOVE COVER
CONVERTIBLE TOP MOTOR	LUGGAGE LOCKER	REMOVE COVER
CONVERTIBLE TOP SWITCH	CENTER CONSOLE	REMOVE TRIM
DIODE — RHD(A)	CENTER CONSOLE, LEFT, UNDER INSULATION	CENTER CONSOLE
PARKING BRAKE SWITCH	PARKING BRAKE	REMOVE TRIM
QUARTER WINDOW MOTOR — LEFT	LEFT REAR WINDOW	BEHIND TRIM COVER
QUARTER WINDOW MOTOR — RIGHT	RIGHT REAR WINDOW	BEHIND TRIM COVER
RELAY — LEFT QUARTER DOWN (HH20)	CONVERTIBLE TOP COMPONENT PANEL	LUGGAGE LOCKER, RIGHT
RELAY — LEFT QUARTER UP (HH21)	CONVERTIBLE TOP COMPONENT PANEL	LUGGAGE LOCKER, RIGHT
RELAY — RIGHT QUARTER DOWN (HH24)	CONVERTIBLE TOP COMPONENT PANEL	LUGGAGE LOCKER, RIGHT
RELAY — RIGHT QUARTER UP (HH25)	CONVERTIBLE TOP COMPONENT PANEL	LUGGAGE LOCKER, RIGHT
RELAY — TOP DOWN (HH22)	CONVERTIBLE TOP COMPONENT PANEL	LUGGAGE LOCKER, RIGHT
RELAY — TOP UP (HH23)	CONVERTIBLE TOP COMPONENT PANEL	LUGGAGE LOCKER, RIGHT
THERMAL BREAKERS	LUGGAGE LOCKER	REMOVE COVER
TRANSMISSION ROTARY SWITCH	LEFT SIDE OF GEARBOX	ON GEARBOX

NOTE: COMPONENT IDENTIFICATIONS WITH [A] OR [B] RATHER THAN A NUMBER INDICATE COMPONENTS WITHOUT JDS DATA BASE IDENTIFICATION. THESE IDENTIFICATIONS ARE PENDING.

CONNECTORS

CODE	DESCRIPTION	LOCATION / INTERFACE
GH7	24-WAY PMHD (YELLOW)	CENTER CONSOLE BY LOWER A/C OUTLET / ROTARY SWITCH HARNESS
GH8	13-WAY SUMITOMO BLOCK (WHITE)	BELOW RIGHT A/C OUTLET / ROTARY SWITCH HARNESS
GH9	14-WAY SUMITOMO BLOCK (WHITE)	BELOW RIGHT A/C OUTLET / ROTARY SWITCH HARNESS
HH18	2-WAY SPADE (WHITE)	LUGGAGE LOCKER / TOP MOTOR
HH19	2-WAY FUSEHOLDER (BLACK)	LUGGAGE LOCKER / CONVERTIBLE TOP FUSE
HH20	RELAY BASE (NATURAL)	CONVERTIBLE TOP RELAY PANEL / LEFT QUARTER DOWN RELAY
HH21	RELAY BASE (YELLOW)	CONVERTIBLE TOP RELAY PANEL / LEFT QUARTER UP RELAY
HH22	RELAY BASE (BLUE)	CONVERTIBLE TOP RELAY PANEL / TOP DOWN RELAY
HH23	RELAY BASE (GREEN)	CONVERTIBLE TOP RELAY PANEL / TOP UP RELAY
HH24	RELAY BASE (BLACK)	CONVERTIBLE TOP RELAY PANEL / RIGHT QUARTER DOWN RELAY
HH25	RELAY BASE (RED)	CONVERTIBLE TOP PANEL / RIGHT QUARTER UP RELAY
HH26	3-WAY SUMITOMO BLOCK (NAT.)	BELOW CONVERTIBLE TOP RELAY PANEL / CONVERTIBLE TOP ECU
HH27	SPADE	FRONT OF CONV. TOP RELAY PANEL / LEFT QUARTER MOTOR THERMAL BREAKER
HH28	SPADE	FRONT OF CONV. TOP RELAY PANEL / LEFT QUARTER MOTOR THERMAL BREAKER
HH29	SPADE	REAR OF CONV. TOP RELAY PANEL / RIGHT QUARTER MOTOR THERMAL BREAKER
HH30	SPADE	REAR OF CONV. TOP RELAY PANEL / RIGHT QUARTER MOTOR THERMAL BREAKER
HH31	6-WAY PM 4 (BLACK)	BETWEEN TOP & REAR QUARTER MOTORS / REAR HARNESS
HH32	6-WAY SUMITOMO STD. (NAT.)	BETWEEN HOOD PUMP & REAR QUARTER / REAR HARNESS
RF5	9-WAY PM 4 (BLACK)	ENGINE COMPARTMENT BY RIGHT PLENUM DRAIN / RF HARNESS
RH133	SPADE	BELOW HAND BRAKE TRIM / PARKING BRAKE SWITCH
RH134	SPADE	BELOW HAND BRAKE TRIM / PARKING BRAKE SWITCH
RH135	SPADE	BELOW HAND BRAKE TRIM / PARKING BRAKE SWITCH
RH145	3-WAY PM 5 (BLACK)	BEHIND REAR QUARTER TRIM / RIGHT QUARTER MOTOR
RH147	3-WAY PM 5 (BLACK)	BEHIND REAR QUARTER TRIM / LEFT QUARTER MOTOR
RH150	6-WAY S/T BLOCK (WHITE)	CENTER CONSOLE / CONVERTIBLE TOP SWITCH
RH161	20-WAY SUMITOMO BLOCK (NAT.)	BELOW LEFT A/C OUTLET / REAR HARNESS

GROUND

CODE	DESCRIPTION	LOCATION / INTERFACE
HG16	EYELET	BETWEEN POWER HOOD PUMP AND REAR QUARTER / POWER GROUND
HG17	EYELET	BETWEEN POWER HOOD PUMP AND REAR QUARTER / POWER GROUND
LIG81	EYELET	ENGINE COMPARTMENT BEHIND ABS PUMP ON BULKHEAD / POWER GROUND
RHG136	EYELET	BASE OF HAND BRAKE / POWER GROUND
RHG149	EYELET	TRANSMISSION TUNNEL / LOGIC GROUND

INPUTS / OUTPUTS

CONVERTIBLE TOP ECU

CODE	IN / OUT	CIRCUIT	ACTIVE	INACTIVE
HH26-1	INPUT	POWER GROUND	GROUND	GROUND
HH26-2	OUTPUT	CONVERTIBLE TOP UP RELAY	GROUND	12V
HH26-3	OUTPUT	CONVERTIBLE TOP DOWN RELAY	GROUND	12V
HH26-4	OUTPUT	LEFT/RIGHT QUARTER DOWN RELAY	GROUND	12V
HH26-5	OUTPUT	LEFT/RIGHT QUARTER UP RELAY	GROUND AFTER 8 SEC. DELAY	12V
HH26-6	INPUT	CONVERTIBLE TOP SWITCH — UP	BUTTON IN: GROUND	BUTTON OUT: 5V
HH26-7	INPUT	CONVERTIBLE TOP SWITCH — DOWN	BUTTON IN: GROUND	BUTTON OUT: 5V
HH26-8	INPUT	IGNITION SWITCHED POWER	12V	0V
HH26-9	INPUT	PARKING BRAKE SWITCH	BRAKE ON: GROUND	OFF: 12V
HH26-10	INPUT	NEUTRAL SWITCH	"P" OR "N": GROUND	"D" OR "R": 12V
HH26-12	INPUT	IGNITION SWITCHED POWER	12V	0V

