


Instruments

WARNING LAMPS AND INDICATORS



JAG1472

1. Anti-lock Braking System (ABS) - USA only.
2. Anti-lock Braking System (ABS) - Canada only.
3. Adaptive Cruise Control (ACC).
4. Active front lighting system (AFL).
5. Engine malfunction.
6. Tire Pressure Monitoring System (TPMS).
7. Air bag.
8. Right-hand direction indicator.
9. Rear fog lamp.
10. Dynamic Stability Control (DSC).
11. High beam.
12. Side lamps.
13. Seat belt.
14. Message center.
15. Automatic Speed Limiter (ASL).
16. Forward alert.
17. Electric Parking Brake (EPB) on/Brake fluid low/Electronic Brakeforce Distribution (EBD) - USA only.
18. Electric Parking Brake (EPB) on/Brake fluid low/Electronic Brakeforce Distribution (EBD) - Canada only.
19. Left-hand direction indicator.

RED warning indicators are for primary warnings. A primary warning must be investigated immediately by the driver or seek qualified assistance as soon as possible.

AMBER warning indicators are for secondary warnings. Some indicate that a vehicle system is in operation, others indicate that the driver must take action and then seek qualified assistance as soon as possible

Other lamps within the instrument panel indicate system status, such as blue for main beam and green for direction indicators, when in operation.