

P0741	Torque converter clutch stuck OFF	Drive vehicle on level road at highway cruising speed; accelerate slowly; decelerate to highway cruising speed	Y	2	N	When fault is detected; - TCM inhibits TCC control	Transmission to TCM pressure regulator 4 circuit open circuit, short circuit or high resistance Transmission internal pressure regulator 4 circuit open circuit, short circuit or high resistance Pressure regulator 4 failure Control valve (valve block) failure Torque converter failure
-------	-----------------------------------	--	---	---	---	---	---