

How to enter code for Jaguar vehicles.

1. To enter your radio code, turn the car's ignition on and then turn the radio on until the word "code" is displayed on the radio faceplate.
2. Enter the correct code by using your "preset buttons" (Buttons you store your "favorite" radio stations to), by firmly pushing on each button.
3. If you have entered the correct code, after the last numeral is entered the radio will beep and then begin to play on the last station selected.
4. If the radio has been "Locked" for a long period of time, or if power has been removed from the radio for an extended period of time, in some cases you will be unable to enter the correct radio code.
5. If this happens, leave the radio powered, with "code" displaying, for at least one hour and then try to re-enter the radio code.

6. The code will usually except after this process.
7. It is not possible to guess at the radio code and to just keep trying combinations of numbers until stumbling on the correct code.
8. The radio will accept only three coding attempts before it locks up for an hour.
9. Then you have three more attempts before it locks up for eight hours, then three more tries before it locks up for 24 hours, and so on.
10. The times indicated may vary.