
1997 XK RANGE - Automatic Transmission/Transaxle - 307-01

The TCM is an integral part of the CAN system which facilitates the interchange of real-time data between control modules and sensors. Please see section **<<303-14>>** for a full description of CAN.

Rotary Switch



The rotary switch:

- Is mounted on the right-hand side of the transmission casing, by means of a locating pin and two bolts.
- Has a 12-way connector on a flying lead; refer to Connector Pins Identification.
- Is operated by the gear selector lever, via the Bowden cable and transmission selector shaft.
- Passes driver requests for gearshift selection to the transmission control module.
- Requires no adjustment or setting procedure.

• Provides the start-inhibit function to the engine control module, which does not allow the engine to start unless the selector lever is in Park or Neutral.