

## KEY OPERATION

---

### Unlocking

#### To unlock and disarm alarm system (United Kingdom and Europe only)

Turn the key towards the rear of the vehicle and release. This unlocks all doors (and the saloon fuel filler flap) and turns on the interior lights for two minutes at  $\frac{3}{4}$  brightness. The direction indicators give two flashes as unlocking takes place.

When the vehicle is unlocked in this manner, a ticking sound will be heard when a door is opened. This is a warning to indicate that the vehicle alarm will activate after seven seconds if the security system is not disarmed with either the key-ring transmitter or by switching the ignition key to position 'II'.

**Note: Unlocking with the key does not disarm the security system, this provides extra protection against thieves.**

With the vehicle disarmed, hold the key in the 'Unlock' position to open all windows and the sports car convertible top, if fitted. This will not open the saloon sunroof, if fitted.

#### To unlock and disarm alarm system (All markets except United Kingdom and Europe)

Turn key towards the rear of the vehicle and release.

This unlocks all doors, luggage compartment, saloon fuel filler flap, disarms the alarm system (if fitted), and turns on the interior lights for two minutes at  $\frac{3}{4}$  brightness. At the same time, the direction indicators will flash twice and two signals will be heard.

Hold the key in the 'Unlock' position to open all windows (and sports car convertible top). If the vehicle is fitted with an alarm system, opening is only possible with the vehicle disarmed.

#### Global Unlocking with Vehicle Armed

First disarm the vehicle with either the key or the transmitter. Put the key into the door lock and hold in the unlock position to open all windows (and the sports car convertible top, if fitted; the saloon sunroof, if fitted will not be opened).

#### Global Unlocking with Vehicle Disarmed

Turn the key to unlock the vehicle and hold in this position to open the windows and the sports car convertible top, if fitted, (the saloon sunroof, if fitted, will not be opened).