NOTE: RELAY COLORS ARE WRITTEN AS CASE COLOR (STRIPE) / CONNECTOR COLOR. FOR EXAMPLE, BLACK (BLUE) / BLUE INDICATES A RELAY HAVING A BLACK CASE WITH A BLUE STRIPE AND A BLUE CONNECTOR. IF THERE IS NO COLOR SHOWN IN PARENTHESES, THE RELAY CASE DOES NOT HAVE A STRIPE.

500A POWER FUSE



FUEL PUMP RELAY 2



LH HEELBOARD RELAYS AND FUSE BOX



LH SEAT RELAYS



LH ENGINE BAY RELAYS AND FUSE BOX



TRUNK RELAYS AND FUSE BOX





WINDSHIELD HEATER RELAYS



250A POWER FUSE



RH HEELBOARD RELAYS AND FUSE BOX



RH SEAT RELAYS



GEARSHIFT AND KEYLOCK RELAYS



RH ENGINE BAY RELAYS AND FUSE BOX