

## NOTICE

Do not use oil additives of any type as engine damage could occur. Use only specified lubricants.

Model	Specification
All engines	SAE 5W-20 meeting Jaguar specification WSS M2C925-A only.

Jaguar recommends:



## TOPPING UP THE OIL

### NOTICE

Overfilling with oil could result in severe engine damage. Oil should be added in small quantities and the level re-checked to ensure that the engine is not overfilled.

1. Unscrew the oil filler cap.
2. Add oil as indicated by the message center display.
3. Wait five minutes for the oil level to stabilize then re-check.

It is essential to use the correct specification oil, and to ensure it is suitable for the climatic conditions in which the vehicle is to be operated.

## ENGINE OIL CONSUMPTION

A certain amount of oil consumption is normal. The rate of consumption will depend on the following:

- The quality and viscosity of the oil.
- Climatic conditions.

- The speed at which the engine is being operated.
- Road conditions.

Drivers should expect above normal consumption when the engine is new, and after breaking-in if high speeds are sustained.

## CHECKING THE COOLANT LEVEL

### NOTICE

Running the engine without coolant will cause serious engine damage.

### NOTICE

If persistent coolant loss is noticed, seek qualified assistance immediately.

The coolant level in the expansion tank should be checked at least weekly (more frequently in high mileage or severe operating conditions). Always check the level when the system is cold.

Ensure the coolant level is maintained between the level indicator marks, as shown in the illustration.



If coolant/steam is expelled from the pressure cap, or the level has dropped suddenly, or by a large amount, arrange for the vehicle to be examined by a qualified technician as soon as possible.